

# Installation Instructions for LJ-3127 Wall Rail Bracket

1. Use the 2" screw into the wall stud on each bracket and tighten. Use blocking behind the drywall if the stud is not accessible.

2. While holding the rail on top of the brackets, attach the brackets to the rail bottom using the 1 1/8" screws. This step may require some assistance.

