

Installation Instructions for LJ-3012 Wall Rail Bracket LJ-3027 Solid Brass Wall Rail Bracket

1. Use one 1 1/2" (for 3012) or 2" (for 3027) screw into the wall stud on each bracket and tighten.
2. While holding the rail on top of the brackets, attach the brackets to the rail bottom using the 1" screws. This step may require some assistance.
3. With proper rail pitch established, install the other two 1 1/2" (for 3012) or 2" (for 3027) screws into the wall stud. Use blocking behind the drywall if the stud is not accessible.

